




# Owner's Manual

---

## LAWN TRACTORS



**Model Numbers**  
**1430**  
**1730**

**Important:**  
**Read Safety Rules and Instructions Carefully**

Thank you for purchasing an American-built product  
**CUB CADET CORPORATION • P.O. BOX 360930 • CLEVELAND, OHIO 44136**

PRINTED IN U.S.A.

FORM NO. 772-4130



## LIMITED WARRANTY

---

Proper maintenance of your Cub Cadet equipment is the owner's responsibility. Follow the instructions in your owner's manual for correct lubricants and maintenance schedule. Your Cub Cadet dealer carries a complete line of quality lubricants and filters for your equipment's engine, transmission, chassis and attachments.

**RIDING MOWERS, LAWN TRACTORS, GARDEN TRACTORS, CUB CADET ATTACHMENTS AND HOME MAINTENANCE PRODUCTS.**

### FIRST YEAR

This limited warranty for residential and commercial users, covers any defect in material or workmanship in your Cub Cadet equipment for one year from the date of purchase for the first user purchaser.

Batteries have a one year prorated limited warranty with 100% replacement during the first three months.

We will replace or repair any part or parts without charge through your authorized Cub Cadet dealer.

### SECOND YEAR

This limited warranty, for residential users only, covers any defects in material or workmanship in the drive train for two years from the date of purchase for the first user purchaser.

The drive train consists of the engine, engine cradle, drive shaft, drive shaft clutch, all parts enclosed by the transmission housing, rear axle housing, brakes and electric power take off (if so equipped). V-belts used for either the traction drive or any attachments are covered for one year only.

### ITEMS NOT COVERED

The warranty does not cover routine maintenance items such as lubricants, filters (oil, fuel, air and hydraulic), cleaning, tuneups, brake and/or clutch inspection, adjustments made as part of normal maintenance, blade sharpening, set-up, abuse, accidents and normal wear. It does not cover incidental costs such as transporting your equipment to and from the dealer, telephone charges or renting a product temporarily to replace a warranted product.

There is no other express warranty.

### HOW TO OBTAIN SERVICE

Contact your authorized Cub Cadet servicing dealer who sold you your Cub Cadet equipment. If this dealer is not available see the Consumer Yellow Pages under "lawn mowers" for the name of a dealer near you.

If you need further assistance in finding an authorized Cub Cadet servicing dealer, contact:

Cub Cadet Corporation  
Post Office Box 360930  
Cleveland, Ohio 44136  
Attn: Customer Service

### HOW DOES STATE LAW APPLY?

This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state.


# CONTENTS

Section	Page	Section	Page
	Warranty .....		2
	Safe Operation Practices .....		3
	To The Owner .....		7
	Serial No. Location .....		7
I	Controls .....		8
II	Operation .....		11
III	Adjustments .....		15
IV	Maintenance .....		20
V	Off-Season Storage .....		25
VI	Mowing .....		26
	Optional Equipment		
	and Accessories .....		27
	Maintenance Chart .....		28
	Trouble Shooting .....		29
	Lubrication Table .....		31
	Lubrication Guide .....		31
	Specifications .....		34
	Slope Gauge .....		35
	Maintenance Parts Chart .....		39

## IMPORTANT

## SAFE OPERATION PRACTICES



THIS SYMBOL POINTS OUT IMPORTANT SAFETY INSTRUCTIONS WHICH, IF NOT FOLLOWED, COULD ENDANGER THE PERSONAL SAFETY AND/OR PROPERTY OF YOURSELF AND OTHERS. READ AND FOLLOW ALL INSTRUCTIONS IN THIS MANUAL BEFORE ATTEMPTING TO OPERATE YOUR UNIT. FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY RESULT IN PERSONAL INJURY. WHEN YOU SEE THIS SYMBOL –  **HEED ITS WARNING.**



### **DANGER:**

This cutting machine is capable of amputating hands and feet and throwing objects. Failure to observe the following safety instructions could result in serious injury or death.

### **GENERAL OPERATION**

1. Read, understand and follow all instructions in the manual and on the machine before starting. Keep this manual in a safe place for future reference and for ordering replacement parts.
2. Only allow responsible adults familiar with the instructions to operate the machine. Know controls and how to stop the machine quickly.
3. Do not put hands or feet under cutting deck or near rotating parts.
4. Clear the area of objects such as rocks, toys, wire, etc. which could be picked up and thrown by the blade. A small object may have been overlooked and could be accidentally thrown by the mower in any direction and cause injury to you or a bystander. Always wear safety glasses or eye shields during operation or while performing an adjustment or repair, to protect eyes from foreign objects. Stop the blade(s) when crossing gravel drives, walks or roads.
5. Be sure the area is clear of other people before mowing. Stop machine if anyone enters the area.
6. Never carry passengers.
7. Disengage blade(s) before shifting into reverse and backing up. Always look down and behind before and while backing.
8. Be aware of the mower and attachment discharge direction and do not point it at anyone. Do not operate the mower without either the entire grass catcher or the chute guard in place.
9. Slow down before turning. Operate the tractor smoothly. Avoid erratic operation and excessive speed.
10. Never leave a running machine unattended. Always turn off blade(s), place transmission in neutral, set park brake, stop engine and remove key before dismounting.
11. Turn off blade(s) when not mowing.
12. Stop engine and wait until blade(s) comes to a complete stop before (a) removing grass catcher or unclogging chute, or (b) making any repairs, adjusting or removing any grass or debris.
13. Mow only in daylight or good artificial light.

14. Do not operate the machine while under the influence of alcohol or drugs.
15. Watch for traffic when operating near or crossing roadways.
16. Use extra care when loading or unloading the machine into a trailer or truck. This unit should not be driven up or down a ramp onto a trailer or truck under power, because the unit could tip over, causing serious personal injury. The unit must be pushed manually to load or unload properly.
17. Never make a cutting height adjustment while engine is running if operator must dismount to do so.
18. Wear sturdy, rough-soled work shoes and close-fitting slacks and shirts. Do not wear loose fitting clothes or jewelry. They can be caught in moving parts. Never operate a unit in bare feet, sandals or sneakers.
19. Check overhead clearance carefully before driving under power lines, wires, bridges or low hanging tree branches, before entering or leaving buildings, or in any other situation where the operator may be struck or pulled from the unit, which could result in serious injury.
20. Disengage all attachment clutches, thoroughly depress the brake pedal and shift into neutral before attempting to start engine.

## **II. SLOPE OPERATION**

Slopes are a major factor related to loss of control and tip-over accidents which can result in severe injury or death. **All slopes** require extra caution. If you cannot back up the slope or if you feel uneasy on it, do not mow it.

### **DO:**

Mow up and down slopes, not across.

Remove obstacles such as rocks, limbs, etc.

Watch for holes, ruts or bumps. Uneven terrain could overturn the machine. **Tall grass can hide obstacles.**

Use slow speed. Choose a low enough gear so that you will not have to stop or shift while on the slope. Always keep tractor in gear when going down slopes to take advantage of engine braking action.

Follow the manufacturer's recommendations for wheel weights or counterweights to improve stability.

Use extra care with grass catchers or other attachments. These can change the stability of the machine.

Keep all movement on the slopes **slow** and **gradual**. Do not make sudden changes in speed or direction. Rapid engagement or braking could cause the front of the machine to lift and rapidly flip over backwards which could cause serious injury.

Avoid starting or stopping on a slope. If tires lose traction, disengage the blade(s) and proceed slowly **straight** down the slope.

For your safety, use the slope gauge included as part of this manual to measure slopes before operating this unit on a sloped or hilly area. If the slope is greater than 15° as shown on the slope gauge, do not operate this unit on that area or serious injury could result.

### **DO NOT:**

**Do not** turn on slopes unless necessary: then, turn slowly and gradually downhill, if possible.

**Do not** mow near drop-offs, ditches or embankments. A wheel over the edge or an edge caving in could cause sudden overturn.

**Do not** mow on wet grass. Reduced traction could cause sliding.

**Do not** try to stabilize the machine by putting your foot on the ground.

**Do not** use grass catcher on steep slopes.

## **III. CHILDREN**

Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the machine and the mowing activity. **Never** assume that children will remain where you last saw them.

1. Keep children out of the mowing area and in watchful care of an adult other than the operator.
2. Be alert and turn machine off if children enter the area.
3. Before and when backing, look behind and down for small children.
4. Never carry children. They may fall off and be seriously injured or interfere with the safe machine operation.
5. Never allow children under 14 years old to operate the machine. Children 14 years and over should only operate machine under close parental supervision and proper instruction.
6. Use extra care when approaching blind corners, shrubs, trees or other objects that may obscure vision.

#### IV. SERVICE

1. Use extra care in handling gasoline and other fuels. They are flammable and vapors are explosive.
  - A. Use only an approved container.
  - B. Never remove gas cap or add fuel with the engine running. Allow engine to cool at least two minutes before refueling. Do not smoke.
  - C. Never refuel the machine indoors.
  - D. Never store the machine or fuel container inside where there is an open flame, or spark, such as a water heater, space heater, clothes dryer and the like.
2. Never run a machine inside a closed area.
3. Check frequently and keep nuts and bolts, especially blade attachment bolts, tight and keep equipment in safe working condition.
4. Never tamper with safety devices. Check their proper operation regularly. Use all guards as instructed in this manual.
5. To reduce fire hazard, keep machine free of grass, leaves or other debris build-up. Clean up oil or fuel spillage. Allow machine to cool before storing.
6. Stop and inspect the equipment for damage if you strike an object. Repair, if necessary, before re-starting and operating the machine.
7. Never make adjustments or repairs with the engine running.
8. Grass catcher components are subject to wear, damage and deteriorate, which could expose moving parts or allow objects to be thrown. Frequently, check components and replace with manufacturer's recommended parts when necessary.
9. Mower blades are sharp and can cut. Wrap the blade(s) or wear gloves and use extra caution when servicing blade(s).
10. Check brake operation frequently. Adjust and service as required.
11. Muffler, engine and belt guards become hot during operation and can cause a burn. Allow to cool down before touching.
12. Do not change the engine governor settings or overspeed the engine.




**DANGER:**

Your unit was built to be operated according to the rules for safe operation in this manual. As with any type of power equipment, carelessness or error on the part of the operator can result in serious injury. If you violate any of these rules, you may cause serious injury to yourself or others.


## PRODUCT GRAPHICS

Keep safety product graphics (decals) clean. Replace any safety graphic that is damaged, destroyed,

missing, painted over or can no longer be read. Replacement safety graphics are available through your dealer.



GENERAL SAFETY INSTRUCTIONS CAUTION -  
LOCATED ON THE FRAME COVER



CAUTION - BOOSTER BATTERY INSTRUCTIONS  
LOCATED UNDER THE SEAT ASSEMBLY

# TO THE OWNER

Assembled in this manual are operation, lubrication, and maintenance instructions for the *Cub Cadet* 1430 and 1730 Tractors. The material has been prepared in detail to help you better understand the correct care and efficient operation of your tractor. Before you operate the tractor, study this manual carefully. Additional copies may be ordered from your dealer at a nominal price.

Your local authorized dealer is interested in the performance you receive from your tractor. He has factory-trained servicemen, informed in the latest method of servicing tractors, modern tools, and original-equipment service parts which assure proper fit and good performance.



## CAUTION

DO NOT tow your tractor. Towing or pushing the tractor for more than a few feet may damage the hydrostatic drive unit.

The tractors have a hydrostatic drive unit and will require minimum service if recommended operation and maintenance procedures are followed.

To obtain top performance and assure economical operation the tractor should be inspected, depending on its use, periodically, or at least once a year, by your authorized dealer.

When in need of parts, always specify the model, chassis, and engine serial numbers, including the prefix and suffix letters. Write these serial numbers in the space provided on this page.

Should you have difficulties with the unit, consult your authorized dealer. UNDER NO CIRCUMSTANCES SHOULD YOU ATTEMPT TO SERVICE THESE UNITS YOURSELF. Only your dealer is authorized to repair or replace units on this drive under the terms of the warranty. Should you desire additional information not found in this manual, contact your authorized *Cub Cadet* dealer.

## SERIAL NUMBER LOCATION



### NOTE

LEFT and RIGHT Indicate the left and right sides of the tractor when facing forward in the driver's seat. Reference to FRONT indicates grille end of the tractor; to REAR the drawbar end.

Chassis serial number plate is on the left hand side of pedestal. (Refer to Figure 1.)




Figure 1

Engine serial number plate is located on the engine shroud. (Refer to Figure 2.)




Figure 2

MODEL \_\_\_\_\_

DELIVERY DATE \_\_\_\_\_

## SECTION I. CONTROLS

Your *Cub Cadet* Tractor has been safety engineered. Thoroughly acquaint yourself with all the instruments and controls before attempting to start or operate the tractor.

### A. CHARGE INDICATOR

This instrument indicates whether the alternator is charging or the battery is discharging. If it shows discharge continuously, investigate the cause to avoid completely discharging the battery and possible damage to the charging circuit. (Refer to Figure 3.)




Figure 3

- A. Charge Indicator
- B. Electronic Monitor
- C. Ignition Switch/Light Switch
- D. Lift Handle
- E. Power Take-Off (PTO)
- F. Brake Pedal
- G. Brake Pedal Lock
- H. Choke Control
- I. Throttle Control Lever
- J. Speed Control Lever
- K. Interlock Safety Switches (not shown)

### B. ELECTRONIC MONITOR (Refer to Figure 4)

In Reverse Gear – will be illuminated when tractor is in reverse. Light must be off to start tractor.

Do Not Engage PTO – will be illuminated while tractor is in reverse.



PTO will not stay engaged with tractor in reverse – switch only will engage.

PTO On – light will be illuminated when PTO switch is engaged. Light must be off to start tractor.

Depress Pedal – light will illuminate when key is in "START" position and brake pedal is not depressed. Light must be off to start tractor.

Full Throttle Required (two indicators) – top light will be illuminated when the PTO is engaged. Bottom light will be illuminated when the light switch is on.



The unit should be run at full throttle when using PTO operated equipment or when the headlights are on.




Figure 4

### C. IGNITION/LIGHT SWITCH



Remove the key from the tractor when the tractor is not in use to prevent accidental starting and battery discharge.

The combination lights and ignition switch is a four-position switch. (Refer to Figure 5.)




Figure 5



#### D. LIFT HANDLE

This lever is used to raise and lower equipment used with the tractor. The equipment can be set in six positions by depressing the button on the top of the lever and releasing it when the desired position is reached. (Refer to Figure 6).




Figure 6

#### E. POWER TAKE-OFF (PTO)

The power take-off is an electric clutch operated by a toggle switch on the left side of the instrument panel. When PTO is engaged, throttle should be in fast position. (Refer to Figure 3.)

#### F. BRAKE PEDAL



#### CAUTION

When the brake pedal is fully depressed, the brake pedal lock will automatically engage. To disengage the brake pedal lock, press down on the pedal slightly. Lift the brake pedal lock up and release the pedal.

The brake pedal is located on the left side of the tractor. When the pedal is fully depressed, the speed control lever is automatically moved to the neutral position if the linkage is properly adjusted. (Refer to Figure 7.)

#### G. BRAKE PEDAL LOCK



#### WARNING

The hydrostatic transmission will not hold the tractor on a hill. In a short period of time

(depending on the steepness of the hill) the oil will drain from the transmission and allow the tractor to roll downhill. To avoid an accident and/or possible injury, lock the brake.

Always lock the brake when tractor is parked on a grade. To lock the brake, depress brake pedal and place the brake pedal lock in the engaged position. (Refer to Figure 7.) To disengage the lock, press down on the pedal, lift the lock up and place it in the disengaged position.




Figure 7

1. Brake Pedal
2. Brake Pedal Lock

#### H. CHOKE CONTROL

The choke control is located on the instrument panel directly below the steering column. The choke control is operated manually. Pull knob out to choke engine. Push knob in to open choke. (Refer to Figure 3.)

#### I. THROTTLE CONTROL LEVER

This lever controls the speed of the engine. When set in a given position, it will maintain a uniform engine speed. (Refer to Figure 3.)

When using power take-off operated equipment, best performance is achieved with the throttle lever in the "FAST" position.



"Turtle" This symbol shows slow position.



"Rabbit" This symbol shows fast position.

#### J. SPEED CONTROL LEVER

The speed control lever is located on the upper right hand side of the instrument panel. Move the speed control lever forward for various forward tractor speeds or backward for various reverse tractor speeds. (Refer to Figure 8.)




Figure 8

### K. INTERLOCKS

This tractor is equipped with a safety interlock system for the protection of the operator. If the interlock system should ever malfunction, do not operate the tractor. Contact your authorized *Cub Cadet* dealer.

The safety interlock system prevents the engine from cranking or starting unless the brake pedal is fully depressed, and the PTO switch is in the "OFF" position.

The safety interlock system will automatically shut off the engine if the operator leaves the seat before placing the speed control lever in neutral ("N") and engaging the brake pedal lock.

The safety interlock system will automatically disengage the PTO if the operator leaves the seat with the PTO on, or the unit is shifted into reverse with the PTO in the "RUN" position. To re-engage the PTO, shift into neutral ("N"), move the PTO switch into the "OFF" position, and then engage the PTO while seated.

### L. HYDROSTATIC DUMP VALVE LEVER

The hydrostatic dump valve lever is located on the frame cover.

The dump valve disconnects the transmission from the pump so the unit can be pushed without running.

1. To engage the dump valve (making the tractor free-wheeling), push the lever forward and hold in this position. (Refer to Figure 9.)
2. To disengage the dump valve, release the lever. (Refer to Figure 10.)

### FUEL TANK AND GAUGE

The fuel tank is on the pedestal, under the hood. The fuel tank cap gauge indicates the amount of fuel in the tank. Remove the cap gauge to fill the tank. Reinstall cap after filling fuel tank. (Refer to Figure 11.)




Figure 9




Figure 10




Figure 11

- |                        |                   |
|------------------------|-------------------|
| 1. Fuel Tank           | 4. Hex Tapp Screw |
| 2. Fuel Tank Cap Gauge | 5. Tube           |
| 3. Pedestal            |                   |

## SECTION II. OPERATION

### PRE-OPERATION CHECKLIST

1. Check oil level. The oil fill and dipstick are located on the right rear side of the engine. (Refer to Figure 12.)
2. Fill fuel tank with Regular or Unleaded gasoline.

### ENGINE OIL REQUIREMENTS

#### *Cub Cadet Low Ash Engine Oil*

Ambient Temperature	Viscosity (Grade SF OR SG)
Above 32°F	SAE 30
Below 32°F	SAE 5W20 or 5W30

**DO NOT USE:** Synthetic oil, non-detergent oil or other non-recommended oils.

**DO NOT MIX** different brands of oil.

### OIL DIPSTICK CHECKS

Dipstick should be checked before starting the unit **EVERY TIME**.

Dipstick markings indicate upper and lower limits at a cold oil condition.

Never overfill engine oil.




Figure 12

### BEFORE OPERATING YOUR TRACTOR

1. Before you operate the tractor study this manual carefully. It has been prepared to help you

operate and maintain your tractor with utmost efficiency.

2. Familiarize yourself with the operation of all the instruments and controls.
3. Fill the tank with either lead-free, low-lead or regular gasoline. Make sure before you fill the tank that the gasoline is clean and fresh.
4. Check tire inflation pressures.
5. Adjust the seat for operator's maximum comfort, visibility and complete control of the tractor.
6. Refer to various sections of the Owner's Manual for additional information.

### STARTING THE ENGINE



#### WARNING

Do not operate tractor if the interlock system is malfunctioning. It is a safety device designed for protection of the operator.



#### NOTE

This unit is equipped with a safety interlock system for your protection. The safety interlock system prevents the engine from cranking or starting, unless the brake pedal is fully depressed, and the PTO engagement switch is in the "OFF" position. The safety interlock system will automatically shut off the engine if the operator leaves the seat before placing the speed control lever in neutral ("N") and engaging the brake pedal lock. The safety interlock system will automatically disengage the PTO if the operator leaves the seat with the PTO on, or the unit is shifted into reverse with the PTO in the "RUN" position. To re-engage the PTO, shift into neutral ("N"), move the PTO switch into the "OFF" position, and then engage the PTO while seated.



#### WARNING

During operation do not run the engine in confined area such as storage building any longer than is necessary. Immediately move the tractor outside into the air.

## **NOTE**

When the engine is still cold it is acceptable to run the unit with the choke pulled out 1/4 inch until the engine is warmed up to prevent engine misfiring.

## **NOTE**

Make sure the carburetor is adjusted as instructed on page 18.

## **WARNING**

Operator must be seated before starting tractor.

1. Operator must be seated.
2. Pull choke control button to full choke position. Less choking may be necessary due to variations in temperature, grade of fuel, etc. Little or no choking will be needed when the engine is warm.
3. Place the throttle in the "START" (1/2-3/4 throttle) position. Never start engine at full throttle.
4. Place the PTO switch to the "OFF" position.
5. Place the speed control lever in neutral ("N").
6. Depress brake pedal all the way down.

## **NOTE**

The speed control lever will automatically return to neutral when the brake pedal is pressed all the way down, and the linkage is properly adjusted.

7. Turn the ignition key clockwise to the "START" position and release it as soon as the engine starts; however, do not operate the starter for more than 10 seconds at any one time. If the engine does not start within this time, turn the key "OFF" and wait a few minutes, then try again.
8. After the engine starts, slowly release the brake pedal and gradually push the choke control button all the way in. Do not use the choke to enrich the

fuel mixture, except as necessary to start the engine.

## **STOPPING THE ENGINE**

### **CAUTION**

Remove the key to prevent accidental starting and battery discharge if equipment is left unattended.

1. Return speed control lever to neutral ("N"), engage the brake pedal lock and return PTO to "OFF" position.
2. Move the throttle lever to the "SLOW" position and allow the engine to idle for a short time before stopping.
3. Then turn the key to the "OFF" position. Remove key from ignition switch.

## **COLD WEATHER STARTING**

### **WARNING**

During operation do not run the engine in confined area such as storage building any longer than is necessary. Immediately move the tractor outside into the air.

## **NOTE**

In cold weather the starting motor may disengage prematurely. This is caused by the engine firing once but failing to continue running. If this happens several times, the engine will be flooded and it will be necessary to leave the throttle in the "SLOW" position but push the choke in all the way; then turn the ignition key to the "START" position and slowly pull the choke out to the position which will cause the engine to start and continue running. If the engine falters after putting tractor into motion, pull the choke out part way until the engine runs smoothly, then gradually push the choke back in as the engine warms.

Engine starting is possible in cold weather providing the correct weight of engine oil is used, the battery is

fully charged, and the proper starting procedure is followed. The best procedure for starting at temperatures near or below freezing is as follows:



### **WARNING**

Operator must be seated before starting tractor.

1. Operator must be seated.
2. Pull the choke all the way out into the full choke position.
3. Place the throttle in the "START" (1/2-3/4 throttle) position. Never start engine at full throttle.
4. Place speed control lever in neutral ("N"), depress brake pedal all the way down, and place PTO switch in "OFF" position.
5. Move the key switch into the "START" position and hold until the engine starts; however, do not operate the starter for more than 10 seconds at any one time. As soon as the engine starts, slowly push the choke in part way.

### **OPERATING IN COLD WEATHER**



### **NOTE**

When the engine is still cold it is acceptable to run the unit with the choke pulled out 1/4 inch until the engine is warmed up to prevent engine misfiring.

### **DRIVING THE TRACTOR**



### **CAUTION**

Avoid sudden starts, excessive speed, and sudden stops. Keep tractor in gear when going down hills.



### **CAUTION**

Do not leave the seat of the tractor without depressing the brake pedal and engaging the brake pedal lock. If leaving the tractor unattended, also turn the ignition key off and remove the key.



### **NOTE**

When using power take-off operated equipment, best performance is achieved with the throttle lever in the "FAST" position.

1. Depress the brake pedal and release the brake pedal lock. Move the throttle lever to the position where the engine operates best for the load to be handled. Release the brake pedal.
2. Start the tractor in motion by moving the speed control lever slowly forward or rearward to desired speed.

**DRIVING ON SLOPES** (Refer to "SLOPE GAUGE" on page 35 in order to help determine slopes where you may not operate safely.)



### **WARNING**

Do not mow on inclines with a slope in excess of 15 degrees (a rise of approximately 2-1/2 feet every 10 feet). A riding mower could overturn and cause serious injury.



### **WARNING**

Operate RIDING mowers up and down slopes, never across slopes.



### **CAUTION**

Always drive up or down the face of a slope. Do not drive so that the tractor may tip over sideways.

Before operating the tractor on any slope, walk the slope to look for possible hazards such as rocks, mounds, ruts, stumps or other surface irregularities which could cause an upset.

Back the tractor with implement up the steepest portion of each slope you intend to work. If the tractor cannot negotiate the slope in reverse, the slope is too steep to be worked.

Avoid turns when driving on a slope. If a turn must be made, turn down the slope. Turning up a slope greatly increases the chance of a roll over.

Avoid stopping when driving up a slope. If it is necessary to stop while driving up a slope, start up smoothly and carefully to reduce the possibility of flipping the tractor over backward.

## STOPPING THE TRACTOR



### CAUTION

Always engage brake pedal lock, lower equipment and shut off engine before dismounting. Never try to start engine from ground.

Depress the brake pedal all the way down, and check that speed control lever is in neutral ("N").



### NOTE

The speed control lever will automatically return to neutral when the brake pedal is pressed all the way down, and the linkage is properly adjusted.

## OPERATING THE FRONT POWER TAKE-OFF CLUTCH (PTO) (Refer to Figure 13.)

1. Move the throttle lever back to the medium or "SLOW" position.

2. Place the speed control lever in neutral ("N").
3. Move PTO switch to "OFF" (A) position. Pull knob out and lift up to "START" (B) position and release.
4. Advance throttle to operating speed (full speed).
5. The operator must remain in tractor seat at all times. If operator should leave tractor seat without turning off the power take-off switch, the PTO will disengage.
6. PTO switch must be in the "OFF" (A) position when shifting the tractor into reverse or the PTO will disengage automatically. To re-engage the PTO, shift unit into neutral. Move PTO switch to "OFF" (A) position. Then pull knob out and lift up to "START" (B) position and release.




Figure 13

## SECTION III. ADJUSTMENTS

### ADJUSTING THE SEAT

Before starting the tractor, adjust the seat to the most comfortable driving position. Tilt the seat forward over the steering wheel, loosen the four adjustment bolts in the seat support, and slide the seat assembly forward or rearward to the position which is most comfortable for the operator. (Refer to Figure 14.)

Retighten the adjustment bolts after the seat is adjusted.




Figure 14

1. Seat Support
2. Adjustment Bolt

### FRAME COVER REMOVAL

1. Remove two screws holding frame cover to frame in the step through area. (Refer to Figure 15.)
2. Remove ball knob from end of dump valve.
3. Lift up and slide frame cover rearward from underneath the pedestal.
4. Reassemble frame cover using two screws.

### ADJUSTING THE POWER TAKE-OFF CLUTCH



### WARNING

To avoid possible injury, always disengage all clutches, move speed control lever into neutral, depress the brake, set the brake pedal lock and turn the ignition "OFF" before working on the machine.




Figure 15

1. Frame Cover
2. Ball Knob
3. Screw

The clutch is factory adjusted and should not require further adjustment under normal operating conditions. However, if the clutch fails to operate properly, check as follows:

Using a feeler gauge, check the air gap. (Refer to Figure 16.) Insert feeler gauge into one of three access slots located around the outside of the brake plate.




Figure 16

1. Access Slots
2. Brake Plate
3. Self-Locking Nuts

The air gap should be .010 to .015 inch. Adjust the self-locking nuts to obtain the proper clearance. Repeat the operation in all three access slots.

## ➔ NOTE

If brake plate drags on clutch at .010 to .015 inch air gap, increase air gap to .020 inch. After two hours of use, recheck and set back to .010 to .015 inch.

If the above procedure does not work, see your authorized dealer.

### ADJUSTING THE BRAKES

During normal operation of this tractor, the brakes are subject to wear and will need periodic examination and adjustment.

To check the brake adjustment, place tractor on a level surface, and engage the hydrostatic dump valve so unit can be pushed. Perform the following checks:

1. Engage the brake pedal lock [when the brake pedal is fully depressed, and the linkage is properly adjusted, the speed control lever will automatically move to the neutral ("N") position]. If the unit can be moved forward or rearward, the brake force must be increased.
2. Release the brake pedal lock. If the unit cannot be moved forward or rearward, the brake force must be decreased.

Refer to the following instructions to increase or decrease brake force.

To increase the brake force, refer to Figure 17 and proceed as follows:

1. Place the tractor on a level surface, with the brake pedal lock disengaged.
2. While working from the rear of the tractor, turn the nut located on the end of the brake rod, clockwise one full turn at a time, until correct adjustment is achieved.

Recheck the adjustment making certain correct adjustment is reached before operating the tractor. If the tractor can still be pushed with brake pedal locked and dump valve engaged, see your authorized *Cub Cadet* dealer.




Figure 17

1. Nut
2. Brake Rod

To decrease brake force, refer to Figure 17 and proceed as follows:

1. While working from the rear of the tractor, turn the nut located on the end of the brake rod, counterclockwise one full turn at a time, until correct adjustment is achieved.

Recheck the adjustment, making certain correct adjustment is reached before operating the tractor. Following this adjustment, release the brake pedal lock and engage the dump valve. If the tractor still cannot be pushed, see your authorized *Cub Cadet* Dealer.

### HYDROSTATIC CONTROLS AND ADJUSTMENT



#### CAUTION

The speed control lever will automatically return to neutral when the brake pedal is pressed all the way down, and the linkage is properly adjusted. If this action fails to occur, contact your authorized *Cub Cadet* Dealer for immediate service.

The following adjustment may be necessary for the hydrostatic adjustment rod if the tractor creeps forward or rearward while the speed control lever is in



the neutral ("N") position. Refer to Figure 18 and while working from rear of tractor with unit off, proceed as follows:

1. If the tractor creeps forward, loosen the jam nut and turn the hex on the control assembly counterclockwise until tractor creep is stopped. When correct adjustment is achieved, retighten jam nut.
2. If the tractor creeps rearward, loosen jam nut and turn the hex on the control assembly clockwise until tractor creep is stopped. When correct adjustment is achieved, retighten jam nut.




Figure 18

1. Jam Nut
2. Control Assembly

## NOTE

If condition is not corrected after performing the above steps, see your authorized *Cub Cadet* Dealer for service.

## PIVOT BAR ADJUSTMENT BOLTS

## CAUTION

The tractor must be checked every 50 hours of tractor operation for play between the front axle and the pivot bar adjustment bolts. Both adjustment bolt heads must fit against the front axle. If play is discovered, the pivot bar adjustment bolts must be adjusted.

If play is discovered between the front axle and the pivot bar adjustment bolt heads, adjust both bolts as follows: (Refer to Figure 19.)

1. Loosen jam nut 3 to 4 turns or as required.
2. Turn pivot bar adjustment bolt counterclockwise until it hits against the front axle.
3. Tighten jam nut.
4. Repeat the above steps for the other pivot bar adjustment bolt.




Figure 19

1. Jam Nut
2. Pivot Bar Adjustment Bolts
3. Front Axle

## WHEEL ALIGNMENT

The front wheels should toe-in approximately 1/8 inch.

Measure the distances A and B on the front wheels. (Refer to Figure 20.)



Dimension B should be approximately 1/8 inch less than dimension A.




Figure 20

## FRONT WHEEL ADJUSTMENTS

To adjust the toe-in remove one ball joint, loosen lock nuts "C" at the ball joint and turn the tie rod ball joint in or out as required. (Refer to Figure 21.)



Tie rod has a bend in the center for clearance of castle nut on pivot bar. Bend must remain down as shown in Figure 21.

## TURNING RADIUS



### CAUTION

Be sure all parts are tightened after completing the following adjustment.

The front wheels should have an equal angle for left and right turns. If adjustment is necessary, remove ball joint and loosen lock nut "D." (Refer to Figure 21.) Turn the drag link ball joint clockwise or counterclockwise as required.




Figure 21  
Tie Rod and Drag Link Ball Joints

1. Castle Nut at Pivot Bar
2. Bend in Tie Rod
3. Lock Nut "D"
4. Lock Nut "C"

## CARBURETOR ADJUSTMENTS (Refer to Figure 22)



### WARNING

If any adjustments are made to the engine while the engine is running (e.g., carburetor), disengage all clutches and blades. Keep clear of all moving parts and be careful of heated surfaces and mufflers.



### WARNING

To avoid injury or an accident, be sure the brake pedal is in the locked position, transmission is in neutral, and any equipment is disengaged before starting engine to make carburetor adjustments.



### WARNING


Carbon monoxide fumes can be fatal! Do not make any adjustments to the carburetor in a confined area such as a storage building. Move the tractor outside into the air.

The carburetor is adjusted at the factory and under normal operating conditions it will not require readjusting. However, if the engine does not operate properly, what may appear to be a faulty carburetor adjustment is in many cases a clogged air filter. This possibility should be ruled out before attempting to readjust carburetor. Refer to "MAINTENANCE" section in this manual.

To prevent possible damage to the carburetor needles, be very careful closing the carburetor needles before basic adjustments are made. Improper adjustment of the carburetor may result in engine damage.

#### **PRELIMINARY SETTINGS (Refer to Figure 22)**

Turn both adjusting needles **out** (counterclockwise) from the closed position, **1-3/8 turns**. Start the engine



**Figure 22**

- 1. High Idle Fuel Needle**
- 2. Low Idle Fuel Needle**
- 3. Low Idle Speed Screw**

and run at half throttle for five to ten minutes to warm up.



The engine must be warm before making final settings.

#### **HIGH IDLE FUEL NEEDLE SETTING**

Place the throttle into the "FAST" position. Turn the high idle fuel adjusting needle **out** (counterclockwise) from the preliminary setting until the engine speed decreases (rich). Note the position of the needle.

Now turn the adjusting needle **in** (clockwise). The engine speed may increase, then it will decrease as the needle is turned in (lean). Note the position of the needle.

Set the adjusting needle **midway** between the rich and lean settings.

#### **LOW IDLE SPEED SETTING**

Place the throttle control into the "IDLE" or "SLOW" position. Set the low idle speed to **1200 RPM** (+ or -75 RPM) by turning the low idle speed adjusting screw in or out.

#### **LOW IDLE FUEL NEEDLE SETTING**

Place the throttle into the "IDLE" or "SLOW" position. Turn the low idle fuel adjusting needle **out** (counterclockwise) from the preliminary setting until the engine speed decreases (rich). Note the position of the needle.

Now turn the adjusting needle **in** (clockwise). The engine speed may increase, then it will decrease as the needle is turned in (lean). Note the position of the needle.

Set the adjusting needle **midway** between the rich and lean settings.

## SECTION IV. MAINTENANCE

### ENGINE OIL

The engine crankcase is filled with ship-away oil. This oil may be used for the first 5 hours of engine operation at temperatures between 0 degrees F. and 90 degrees F. If temperatures are not within this range, drain the oil from the oil filter, if installed, and crankcase and replace with new oil as specified in the "LUBRICATION TABLE." The engine oil must be drained and replaced with new oil every 50 hours of engine operation.

To aid starting, the selection of crankcase lubricating oils should be based on the lowest anticipated temperatures until the next drain period.

*Cub Cadet* Low Ash Engine Oil meeting API Service Classification SF or SG is recommended. For maximum engine life select API SF or SG oils with lowest levels of barium, calcium, or magnesium additives and minimum ash content (approximately 0.5%). Lubricant suppliers will normally furnish this information on their engine oils.

### OIL LEVEL CHECK

Before each use, the oil level of the engine crankcase should be checked to see that it is filled to correct level. Close monitoring of the oil level during the first 10 hours of operation of the engine is especially important. Always keep the oil level between the "FULL" and the "LOW" marks on the dipstick. When checking the oil level the dipstick must be withdrawn and wiped clean, then inserted all the way and withdrawn for a true reading.



#### NOTE

Check the oil level only while the engine is stopped and tractor is level.



#### CAUTION

The oil level should be checked every hour during the first 5 hours of operation.



#### NOTE

The engine oil level should be checked prior to every use.

### FILLING THE CRANKCASE

To fill the crankcase with oil, place the tractor on a level surface. Clean the area around the oil fill tube

and dipstick to prevent debris from entering the crankcase.



#### NOTE

Never overfill the engine crankcase. Engine may overheat and/or damage may result if the crankcase is below the "LOW" mark or over the "FULL" mark. For oil capacity refer to the **SPECIFICATIONS** and **LUBRICATION TABLE** sections.



#### NOTE

For best results, fill only to "F" mark only on dipstick as opposed to adding a given quantity of oil. Always check level on dipstick before adding more oil.

Remove the oil fill cap and dipstick and fill to the full mark on the dipstick. **POUR SLOWLY.** The oil capacity is 4 pints. When checking the oil level, push the dipstick assembly firmly but slowly until cap bottoms on tube. **DO NOT OVERFILL.** Dipstick assembly **MUST BE PUSHED FULLY INTO TUBE AT ALL TIMES WHEN ENGINE IS OPERATING.**

### OIL CHANGE PROCEDURE



#### NOTE

The engine oil should be changed after the first 5 hours of operation.

Refer to the **MAINTENANCE CHART** and the **LUBRICATION TABLE** for information regarding the frequency of oil change and the quantity and type of oil needed. While the engine oil is warm, proceed as follows:



#### WARNING

Oil may be hot. Use care to avoid burns from hot oil.

1. Place the tractor on a level surface, and engage brake pedal lock. Remove the drain plug and collect the old oil in an adequate container. (Refer to Figure 23.)
2. Remove the oil filter by turning it counterclockwise.

3. Apply a light coat of oil to rubber seal on oil filter. Install filter turning it clockwise. Filter should be snug plus 1/2 turn.
4. Replace the drain plug.
5. Refer to **"FILLING THE CRANKCASE"** and **"LUBRICATION GUIDE"** and refill the crankcase.




Figure 23

## AIR CLEANER

### Servicing Foam Pre-Cleaner Element

Clean and re-oil foam pre-cleaner element at 1-month intervals or every 10 hours, whichever occurs first.



### NOTE

Service more often under dusty conditions.

1. Remove wing nut and cover. (Refer to Figure 24.)
2. Remove foam pre-cleaner element by sliding it up off the paper cartridge.
  - A. Wash pre-cleaner element in liquid detergent and water.
  - B. Squeeze dry in cloth.
  - C. Saturate in engine oil. Squeeze to distribute oil evenly.
  - D. Wrap in shop towel and squeeze to remove excess oil.

Discard used element and replace with new one at least once a year.




Figure 24. Air Cleaner Assembly

1. Wing Nut
2. Cover
3. Rubber Tube
4. Cover Plate
5. Paper Cartridge
6. Foam Pre-Cleaner Element
7. Base Backplate

### SERVICING PAPER CARTRIDGE

This engine is equipped with a dry type air cleaner element, which should be checked every 100 operating hours and replaced if dirty. It should be checked and if necessary replaced more often under extremely dirty, dusty conditions. Do not wash element in any liquid or attempt to blow dirt off with air hose as this will puncture filter element. Carefully handle new element — do not use if gasket surfaces are bent or twisted. Check the following when installing a new element: (Refer to Figure 24.)

1. Backplate must be flat on gasket of carburetor elbow. Replace backplate if bent or cracked.
2. Gasket surfaces of element must be flat against backplate and covered to seal effectively.
3. Seal on cover must be in place to reduce noise and vibration of the cover. Vibration can cause

stud hole in cover to enlarge, thus permitting dirt to enter carburetor.

4. Wing nut must be finger tight — do not over-tighten.

Properly cleaned and installed air cleaner elements are the best guarantee to continued long and satisfactory engine life.

### CLEANING ENGINE

This tractor has an air-cooled engine. Air must be able to circulate freely around the engine, through the screen, shroud, and over the fins of the cylinder head and cylinder block. Keep these areas free of accumulated dirt and trash or engine will overheat and result in damaged moving parts.

### SPARK PLUGS



#### WARNING

To avoid possible injury, be sure engine is off and cool before making any adjustment or repairs.



#### NOTE

Remove all dirt from around the spark plugs before removing.

To remove spark plugs, always use a spark plug wrench. Check gap after every 100 hours of operation.

Replace a defective plug with a new plug. Set gap at .025 inch. (Refer to Figure 25.) Tighten plug to 10-15 ft-lbs. See your authorized dealer for the correct replacement plug.




Figure 25

#### 1. Spark Plug

### CLEANING OF CYLINDER HEADS

Cleaning of the cylinder heads should only be done by your authorized *Cub Cadet* Dealer. This process is to be done to keep your engine properly cooled and at its peak efficiency. The frequency of cleaning is dependent upon the type of fuel used. When leaded fuel is used the cleaning interval is 250 hours, and with unleaded fuel the cleaning interval is 500 hours.

### FUEL FILTER



#### WARNING

Do not replace fuel filter when engine is hot.

The engine is equipped with an inline fuel filter. Visually inspect the filter periodically. Replace dirty filter.

### HYDROSTATIC TRANSAXLE

This is a sealed unit. It should only be serviced by an authorized *Cub Cadet* Dealer.

### HYDROSTATIC TRANSMISSION

This is a sealed unit. It should only be serviced by an authorized *Cub Cadet* Dealer.

### DRIVE BELT REPLACEMENT

If drive belt replacement is required, contact your authorized *Cub Cadet* Dealer.

### BATTERY INFORMATION



#### WARNING

- A. Battery acid must be handled with great care as contact with it can burn and blister the skin. It is also advisable to wear protective clothing (goggles, rubber gloves and apron) when working with it.\*
- B. Should battery acid accidentally splatter into the eyes or onto the face, rinse the affected area immediately with clean cold water. If there is any further discomfort, seek prompt medical attention.
- C. If acid spills on clothing, first dilute it with clean water, then neutralize with a solution of ammonia/water or baking soda/water.
- D. Since battery acid is corrosive, do not pour it into any sink or drain. Before

discarding empty electrolyte containers, rinse them with a neutralizing solution.

- E. NEVER connect or disconnect charger clips to battery while charger is turned on as it can cause sparks.
- F. Keep all lighted materials (cigarettes, matches, lighters) away from the battery as the hydrogen gas generated during charging can be combustible.
- G. As a further precaution, only charge the battery in a well-ventilated area.

\* Always shield eyes and protect skin and clothing when working near batteries.



## DANGER

BATTERIES CONTAIN SULFURIC ACID AND MAY CONTAIN EXPLOSIVE GASES (when electrolyte has been added).

KEEP BATTERIES OUT OF THE REACH OF CHILDREN.

## MAINTENANCE OF BATTERY

1. Check electrolyte level periodically (at least every two weeks). Keep the level to the split rings. Use only distilled water or a good quality drinking water. Never add acid or any other chemicals to the battery after initial activation.
2. The battery should be checked with a hydrometer after every 25 hours of operation. If the specific gravity is less than 1.225, the battery should be recharged. Maximum charge rate 5 amps.
3. Coat the terminals and exposed wire with a thin coat of grease or petroleum jelly for longer service and protection against corrosion.
4. The battery should be kept clean. Any deposits of acid should be neutralized with baking soda and water. Be careful not to get this solution in the cells.
5. Avoid tipping the battery. Even a "sealed" battery will leak electrolyte when tipped.

## STORAGE OF THE BATTERY

1. When storing battery for extended periods, disconnect battery cables. Removing battery from unit is recommended.

2. Keep the exterior of the battery clean, especially the top. A dirty battery must be stored with a full charge. A dirty battery will discharge itself.
3. Check the battery with a hydrometer. The battery must be stored with a full charge. A discharged battery will freeze.

### Specific Gravity

1.265  
1.250  
1.200  
1.150  
1.100

### Freezing Point

-71°F  
-62°F  
-16°F  
5°F  
16°F



## NOTE

All batteries discharge during storage.

4. Recharge battery whenever the specific gravity is less than 1.225, before returning to service or every two months, whichever comes first.

## COMMON CAUSES FOR BATTERY FAILURE

1. Overcharging
2. Undercharging
3. Lack of water
4. Loose hold downs and/or corroded connections
5. Excessive loads
6. Battery electrolyte substitutes
7. Freezing of electrolyte



## NOTE

These failures do not constitute warranty.

## BATTERY REMOVAL OR INSTALLATION



## WARNING

When removing the battery, follow this order of disassembly to prevent your wrench from shorting against the frame.

1. Remove the Negative cable.
2. Remove the Positive cable.

### To install a battery:

1. Attach the Positive cable.
2. Attach the Negative cable.

### JUMP STARTING



#### WARNING

Failure to use this starting procedure could cause sparking, and the gases in either battery could explode.

1. Attach the first jumper cable from the positive terminal of the good battery to the positive terminal of the dead battery.
2. Attach the second jumper cable from the negative terminal of the good battery to the FRAME OF THE UNIT WITH THE DEAD BATTERY.

### TIRES

Keep the pneumatic tires properly inflated. Overinflation will cause operator discomfort. Underinflation will cause short tire life.

Inflate the front and rear tires for normal or heavy load operations as shown in the following table:

Tire Size	Pounds per Square Inch
Front Tires 15 x 6-6	12
Rear Tires 20 x 10-8	10

Always see that the tire valve caps are in place and tightened securely to prevent loss of air and protect the valve core and stem.

Do not overload the tractor tires by mounting equipment on the tractor which exceeds the load capacity of the size of the tires on the tractor.

### MOUNTING TIRES ON THE RIM

After mounting a new or old tire on the rim, inflate it to 20 pounds pressure to seat the tire bead on the rim flange. Then deflate the tire to the correct operating pressure.



#### NOTE

After the first 10 hours of operation, check and retorque the front wheel bolts to 35 ft-lbs. and rear wheel bolts to 23 ft-lbs. to make sure they have seated properly.



## SECTION V. OFF-SEASON STORAGE

If the machine is to be inoperative for a period longer than 30 days, the following procedures are recommended:



### WARNING

Never store engine with fuel in tank indoors or in poorly ventilated enclosures, where fuel fumes may reach an open flame, spark or pilot light as on a furnace, water heater, clothes dryer, etc.

1. Remove all gasoline from fuel tank to prevent gum deposits from forming on these parts and causing possible malfunction of engine.

Run engine until engine starts to falter, then use choke to continue engine operation until all fuel in tank and carburetor is exhausted. Remove fuel line at tank or carburetor and drain any remaining gasoline from system.



### WARNING

Drain fuel into approved container outdoors, away from open flame.

Fuel left in engine during warm weather deteriorates and will cause serious starting problems.

2. Remove spark plugs and pour one (1) ounce of engine oil through spark plug hole into cylinder. Crank engine several times to distribute oil. Replace spark plugs.
3. Clean the engine and the entire tractor thoroughly.
4. Lubricate all lubrication points and wipe the entire machine with an oiled rag in order to protect the surfaces.
5. Follow battery storage instructions on page 23.
6. Protect tires and seat from sunlight. Inflate tires at regular intervals.

## SECTION VI. MOWING

### STARTING THE MOWER



#### NOTE

In heavy grass, full throttle may be needed when starting the mowing deck.

With the engine running at idle speed, start the power take-off clutch (see page 14, Figure 13). Starting the mower with the engine in idle will reduce wear on the drive belt. Increase engine speed to full throttle.

### STOPPING THE MOWER

Move the power take-off (PTO) switch to "OFF" and reduce engine speed.

### MOWING



#### WARNING

To avoid possible injury, do not allow anyone in the area opposite the discharge chute while mowing. Although the area has been supposedly cleared of foreign objects, small objects may be discharged by the mower.



#### WARNING

Never direct discharge of material toward bystanders or allow anyone near the machine while in operation.

For best results it is recommended that the first two laps should be cut with the discharge thrown towards the center. After the first two laps, reverse the direction to throw the discharge to the outside for the balance of cutting. This will give a better appearance to the lawn.

Do not cut the grass too short, as the mower will tend to scalp the grass. Short grass invites weed growth and yellows quickly in dry weather.

Mowing should be done with the engine at full throttle. Do not mow at high ground speed.

During certain times of the year and under some conditions, the mower may leave streaks of uncut material.

Streaking may occur when attempting to mow heavy weeds and tall grass. Under these conditions it may be necessary to go back over the cut area a second time to get a clean cut.

The following practices will help eliminate streaking:

1. Mow the area more often so the grass doesn't get too tall and heavy.
2. Operate the tractor at full throttle and lower forward speeds.
3. Keep the blades sharp and replace blades when worn.
4. Follow the mowing procedure shown in Figure 26.




Figure 26

## OPTIONAL EQUIPMENT AND ACCESSORIES

When you purchased your tractor, you probably had it completely equipped for your particular needs at the time. However, later you may wish to obtain optional equipment or accessories. These items and other allied equipment can be purchased from, and installed by, your authorized dealer.

The tractor is used for so many different types of work, and because it is called on to operate under so many different conditions, a variety of equipment is available to adapt it to the requirements of the user. **Refer to attachment guide for a complete description of equipment and required components that can be utilized with your tractor.**

# MAINTENANCE CHART

Operation to be performed	Before each use	10 hours or once a month	50 hours	100 hours or yearly	Before storage
Clean grille (front & backside) & engine inlet air screen		More often under dirty conditions X			
Check engine oil level	X				
Fill fuel tank	X				
Cylinder head cleaning	Leaded fuel — 250 hours Unleaded fuel — 500 hours				
Change engine oil and filter	After first 5 hours		X		
Check battery electrolyte level		X			
Grease front axle pivot bolt		X			
Lubricate steering knuckles (2) and steering arm		X			
Retorque rear and front wheel bolts		After first 10 hours X		X	
Lubricate brake shaft			X		
Clean cooling fins & external surfaces			X		
Service air cleaner				More often under dirty conditions	
Check spark plugs				X	X
Lubricate speed control linkage cam plates				X	
Grease front wheel bearings			X		X
Drain fuel					X
Pivot bar adjustment bolt			X		
Movable idler bracket			X		
Steering gear			X		

## NOTE

Maintenance information for optional equipment may be found in the manual which is included with the specific piece of optional equipment.

# TROUBLE SHOOTING

## Possible Cause

## Possible Remedy

### HARD TO START

No gasoline in fuel tank or carburetor .....	Fill the tank with gasoline. Check the fuel line and carburetor.
Fuel line or carburetor clogged .....	Clean the fuel line and carburetor with commercial carburetor cleaner.
Water in gasoline .....	Drain the fuel tank and carburetor. Use new fuel and dry the spark plug.
Choked improperly. Flooded engine .....	Follow the starting instructions.
Defective ignition or loose wiring .....	Check the wiring, spark plug, or fuse.
Defective battery .....	Check and service. Refer to <b>"BATTERY."</b>
Spark plug dirty or improper gap .....	Clean, adjust the gap to .025-inch or replace the plug.

### ENGINE OPERATES IRREGULARLY OR KNOCKS

Engine incorrectly timed .....	*
Spark plug dirty; wrong gap or wrong type .....	Clean, reset the gap, or replace.
Poor or weak spark .....	Check the spark plug and wiring.*
Carburetor setting incorrect .....	Adjust. Refer to <b>"ADJUSTMENTS"</b>
Poor grade fuel or water in fuel .....	Drain and use a good grade of clean fuel.
Engine overheating .....	Refer to <b>"MAINTENANCE."</b>
Engine valves at fault .....	*
Engine smokes .....	Adjust the carburetor.*
Oil level will rise due to gasoline in crankcase .....	Refer to <b>"OPERATING IN COLD WEATHER."</b>
Air filter will become oil and fuel soaked .....	Refer to <b>"OPERATING IN COLD WEATHER."</b>
Engine leaks oil .....	Refer to <b>"OPERATING IN COLD WEATHER."</b>
Misfiring .....	Refer to <b>"OPERATING IN COLD WEATHER."</b>
Other engine problems .....	*
Excessive oil in air cleaner .....	Be sure that oil dipstick is fully seated and all excess oil is squeezed out of pre-cleaner foam element.

### LACK OF POWER

Air cleaner clogged .....	Service the air cleaner element. Refer to <b>"MAINTENANCE."</b>
Engine overload .....	Reduce the load.
Engine overheated .....	Make sure air intake screen, shrouding, engine fins, and grille are free of accumulated dirt and trash. Refer to <b>"MAINTENANCE."</b>
Poor fuel, too rich, or too lean a mixture .....	Refer to <b>"ADJUSTMENTS."</b>
Fuel tank air vent clogged .....	Open the vent in the cap.
Air leakage between carburetor and engine .....	Remove air cleaner. Tighten the carburetor and manifold mounting nuts. Replace as indicated in <b>"MAINTENANCE."</b>

\*See your authorized dealer.

# TROUBLE SHOOTING

## Possible Cause

## Possible Remedy

### LACK OF POWER (Cont)

Incorrect timing or faulty ignition .....	*
Brake drags .....	Adjust the brake. Refer to "ADJUSTMENTS."

### ENGINE OVERHEATING

Insufficient cool air, dirty air intake screen, shroud, cooling fins, or dirty grille .....	Keep the air intake area and cooling fins clean; refer to "MAINTENANCE."
Lean carburetor adjustment .....	Readjust. Refer to "ADJUSTMENTS."
Oil level incorrect .....	Engine oil level must not be over the "FULL" mark or below the "LOW" mark. Refer to "MAINTENANCE."

\*See your authorized dealer.

# LUBRICATION TABLE

Point of Lubrication	Check at Hours	Change at Hours	Capacity	Anticipated Air Temperature	
				Above +32°F	Below +32°F
Engine crankcase	Check before each use	50	4 pints	<i>Cub Cadet</i> Low Ash Engine Oil SAE 30	<i>Cub Cadet</i> Low Ash Engine Oil SAE 5W20 or 5W30
Steering knuckles & front axle pivot bolt	10		Use 251H EP grease or equivalent No.2 multi-purpose lithium grease and apply two or three strokes or sufficient grease to flush out old grease and dirt.		
Front wheel bearings	50		Two or three strokes minimum of the lubricator using 251H EP grease or equivalent No. 2 multi-purpose lithium grease.		
Steering gear	50		Turn the steering wheel fully to the right and brush on 251H EP grease or equivalent No. 2 multi-purpose lithium grease to the steering gear. Turn the steering wheel in both directions to disperse the grease.		

## LUBRICATION GUIDE

The life of any machine depends upon the care it is given. Proper lubrication is a very important part of that care.

Be certain that all lubrication fittings are assembled in place, using the lubrication illustrations as a guide.

Always lubricate the tractor thoroughly before taking it to the field. Use a pressure lubricating gun.

Be sure all fittings are free from dirt and paint so the lubricant is certain to enter the bearing.

Always force the lubricant through the full length of each bearing until it emerges at the end, carrying with it the worn lubricant and any dirt that may have entered the bearing.

Miscellaneous work parts not provided with lubrication fittings should be oiled periodically with a good grade of lubricating oil.

Lubricant is cheap. Use plenty of it. Worn parts can be expensive to replace.

Keep your supply of lubricating oil and grease stored in clean containers, and covered to protect from dust and dirt.

Keep the lubricating gun nozzle clean and wipe dirt from grease fittings before lubricating.

The symbols in the illustration indicate the method of application and the hourly intervals to apply the lubricant.



Use a pressure lubricating gun and apply 251H EP grease (or equivalent No. 2 multi-purpose lithium grease) sufficient to flush out the old grease and dirt. Lubricate at hourly intervals indicated on symbols.



Dipstick, use to check engine oil before each use.

# LUBRICATION GUIDE

## —BEFORE EACH USE

1. Engine filler cap and dipstick

Check the oil (with the engine stopped) and add sufficient new oil to bring it to the "FULL" mark on the dipstick. Do not overfill. Do not operate the engine if the oil level is below the "LOW" mark on the dipstick.

## —AFTER EVERY 10 HOURS OF OPERATION

2. Steering knuckles (2)  
(Both sides)
3. Front axle pivot bolt  
(Right side)

Use 251H EP grease or equivalent No. 2 multi-purpose lithium grease and apply sufficient grease to flush out old grease and dirt.

Use 251H EP grease or equivalent No. 2 multi-purpose lithium grease and apply sufficient grease to flush out old grease and dirt.

**NOTE:** It may be necessary to rotate the front axle to reach the grease fitting.

## —AFTER EVERY 50 HOURS OF OPERATION

4. Engine oil drain plug

While the engine oil is warm, remove the drain plug and drain all of the oil from the crankcase. Remove oil filter and replace with a new one. Replace the drain plug. Refer to "MAINTENANCE" "FILLING THE CRANKCASE" for proper oil filling procedure. Refer to "LUBRICATION TABLE" for the proper quantity and viscosity to use.

5. Steering gear

Turn the steering wheel fully to the right and brush on 251H EP grease or equivalent No. 2 multi-purpose lithium grease to the steering gear. Turn the steering wheel in both directions to disperse the grease.

6. Movable Idler bracket

Use 251H EP grease or equivalent No. 2 multi-purpose lithium grease and apply sufficient grease to flush out old grease and dirt.

7. Front wheel bearings

Two or three strokes minimum of the lubricator using 251H EP grease or equivalent No. 2 multi-purpose lithium grease.

## —EVERY 100 HOURS OF OPERATION

### Speed Control Linkage

8. Cam plates

Once a year, apply a small amount of 251H EP grease or equivalent No. 2 multi-purpose lithium grease in the slots.

### Miscellaneous

- Brake pedal shaft


Lubricate the brake pedal shaft and linkage with eight or ten drops of engine oil.



Lubrication information for optional equipment may be found in the manual which is included with the specific piece of optional equipment.



## LUBRICATION GUIDE



# SPECIFICATIONS


	1430 and 1730
<b>CAPACITIES</b>	
Fuel tank .....	3 gals.
Crankcase .....	4 pints
<b>HYDROSTATIC DRIVE</b>	
Speed: Forward .....	0 to 5.5 mph
Reverse .....	0 to 3.0 mph
<b>ENGINE</b>	
Make and model .....	Kohler
(electric starting) .....	14 HP (1430) 17 HP (1730)
Cylinders .....	2
Bore .....	3.75 in.
Stroke .....	3.25 in.
Displacement (cubic inches) .....	35.90
Compression ratio .....	5.8 - 1 (1430) 6.0 - 1 (1730)
Engine speed .....	(governed)
Low speed .....	1350 RPM
High idle speed (no load) .....	3400 RPM $\pm$ 75
Valve clearance (engine cold) .....	.003/.006 in. (intake) .011/.014 in. (exh.)
Ignition .....	Battery
Spark plug .....	Cub Cadet No. 759-3334
Spark plug gap .....	.025 in. gap
<b>ELECTRICAL SYSTEM</b>	
System voltage .....	12 volt neg. ground
Battery .....	Cub Cadet No. 725-3061
Alternator .....	15 amp
Fuse (autotype) .....	20 amp
Headlights (bulb) .....	GE 12 volt 1141
<b>BRAKES</b> .....	Single disc, external
<b>TIRE SIZES</b>	
Front .....	15 x 6-6
Rear .....	20 x 10-8
<b>GENERAL</b>	
Wheelbase .....	45.0 in.
Length, over-all .....	68.50 in.
Turning radius .....	29.00 in.
Available mower sizes .....	38, 44 or 46 inches
Adjustable cutting height (approx) .....	1-1/2 to 4 inches
Mower drive .....	V-belt with electric clutch

Specifications are subject to change without notice.

# SLOPE GAUGE

(Keep this sheet in a safe place for future reference.)

USE THIS SHEET AS A GUIDE TO DETERMINE SLOPES WHERE YOU MAY NOT OPERATE SAFELY.










Do not mow on inclines with a slope in excess of 15 degrees (a rise of approximately 2½ feet every 10 feet). A riding mower could overturn and cause serious injury. If operating a walk-behind mower on such a slope, it is extremely difficult to maintain your footing and you could slip, resulting in serious injury.

Operate RIDING mowers up and down slopes, never across the face of slopes.

Operate WALK-BEHIND mowers across the face of slopes, never up and down slopes.

## MAINTENANCE PARTS CHART

MODEL 1430 MODEL 1730		LAWN TRACTOR 14 HP KOHLER LAWN TRACTOR 17 HP KOHLER			
<b>ENGINE OIL</b> 	<b>Engine Oil Requirements . . . . . 4 pints</b>			<b>Part No.</b>	
	Cub Cadet low ash engine oil Ambient temperature viscosity (Grade SF or SG) Above +32°F                      SAE 30 Below +32°F                      SAE 5W20 or 5W30			737-3029 737-3049 (5W30)	
<b>AIR FILTER</b>  <b>CARTRIDGE</b>  <b>FOAM PRE-CLEANER</b>	<b>Air Filter Requirements</b>			<b>Part No.</b>	
	Clean air filter per instructions in your owner's manual . . . . . under maintenance air cleaner.			Cartridge 759-3359  Foam Pre-cleaner KH-45 083 01	
<b>OIL FILTER</b> 	<b>Oil Filter Requirements</b>			<b>Part No.</b>	
	Change every 50 hours			KH-52 050 02	
<b>SPARK PLUG</b> 	<b>Gap Requirements</b>			<b>Part No.</b>	
	.025 inch gap			759-3334	
<b>BELTS</b> 	<b>Transaxle Belt</b>		<b>Deck Blade Belt</b>		<b>Tractor to Deck Belt</b>
	<b>Model</b>	<b>Part No.</b>	<b>Model</b>	<b>Part No.</b>	<b>Model      Part No.</b>
	1430	754-3037	38" Deck	754-3036	38" Deck    754-3029
	1730	754-3037	44" Deck	754-3027	44" Deck    754-3029
			46" Deck	754-3039	46" Deck    754-3029
<b>BLADES</b> 					
<b>Original Equipment Blade</b>		<b>Bagging Blade</b>		<b>Hard Coated Bagging Blade</b>	
<b>Size</b>	<b>Part No.</b>	<b>Size</b>	<b>Part No.</b>	<b>Size</b>	<b>Part No.</b>
38"	742-3009 (2)*	38"	742-3008 (2)	38"	759-3396 (2)
46"	742-3015 Center (1) 742-3016 Outer (2)	46"	742-3010 Center (1) 742-3011 Outer (2)	46"	759-3398 Center (1) 759-3397 Outer (2)
<b>Original Equipment Blade</b>				<b>Hard Coated Blade</b>	
<b>Size</b>	<b>Part No.</b>			<b>Size</b>	<b>Part No.</b>
44"	742-3002 (3)			44"	759-3402 (3)

Original Equipment Blade – Hard Coated 759-3395 (2)